



PC Cable Pin Connection

PC Side		PCBL-31	Controller Side	
Signal	Pin No.		Pin No.	Signal
RXD	2		2	GND
TXD	3			
DTR	4		5	TXD
GND	5		6	RXD
DSR	6			
RTS	7		8	GND
CTS	8		FG(Ground Plate)	
FG	Hood			FG




Controller Side		PCB-31	PC Side	
Signal	Pin No.		Pin No.	Signal
FG	1			
TXD	2		2	RXD
RXD	3		3	TXD
RTS	4		4	DTR
CTS	5		5	GND
DSR	6		6	DSR
GND	7		7	RTS
			8	CTS
DTR	20			



TOSHIBA MACHINE

Controller Side		PCBL-98	PC Side		
D-SUB 25pin			MDR 14pin		
Signal	Pin No.		Pin No.	Signal	
FG	1	●	●	FG(Ground Plate)	
TXD	2	●	●	2	GND
RXD	3	●	●		
RTS	4	●	●	5	TXD
CTS	5	●	●	6	RXD
DSR	6	●	●		
GND	7	●	●	8	GND
DTR	20	●	●		



D-SUB 25pin		PCB-98	D-SUB 25pin		
Signal	Pin No.		Pin No.	Signal	
FG	1	●	●	1	FG
TXD	2	●	●	2	TXD
RXD	3	●	●	3	RXD
RTS	4	●	●	4	RTS
CTS	5	●	●	5	CTS
DSR	6	●	●	6	DSR
GND	7	●	●	7	GND
DTR	20	●	●	20	DTR

